



SMARTFOX®



SMARTFOX Pro 2

Operating instructions

Manual Version 12 - 04.2022 SMARTFOX

Version - EM2 00.01.03.17 | V.3.17

DECLARATION SAFETY INSTRUCTIONS

WARNING

Non-compliance can lead to damage to property and personal injury. The instructions given must therefore always be observed or implemented!

ATTENTION

Non-compliance can lead to malfunctions or damage to the unit. The instructions given must therefore always be followed or implemented!

NOTE

Useful tips to support you during commissioning. The instructions given are not mandatory.

TABLE OF CONTENTS

General Information	4
General Notes	4
Conformity	4
Application	4
Function	4
Scope of delivery and technical data	5
Regulations	6
Dimensions	6
Assembly	6
Electrical connection	6
Hedging	6
Installation of SMARTFOX current transformers	7
SMARTFOX Additional current transformer	8
Wiring diagram	9
Power controller & heating element 1-phase	9
Power controller & heating element 3-phase	10
Consumer via relay	11
Navigation through the menu	12
Instructions for firmware update	13
Displaying the measured values	14
Main menu	18
Settings menu	22
Settings General	22
Settings Network (LAN / WLAN)	24
Settings Analogue output	26
Settings relays 1-4	29
Settings Relay Special functions	33
Settings Inputs and consumption controller	36
Settings inverter, heat pump, battery	38
Settings Car Charger	39
Maintenance menu	40
Local Network access	41
Connection with my.smartfox.at	42
Troubleshooting	43

GENERAL INFORMATION

General Notes

These operating instructions are part of the scope of delivery. They contain the information required for proper use. They are intended for electrical engineering personnel or specialists who are familiar with the installation, assembly and commissioning of the product described here. If further information is required, it can be requested from the contact details on page 44.

Conformity

This appliance complies with the provisions of the Directive of the Council of the European Communities on the approximation of the laws of the EC Member States relating to electromagnetic compatibility, EMC Directive 2004/108/EC, and the Low Voltage Directive 2006/95/EC.

Application

The "SMARTFOX Pro 2" energy consumption controller is used to optimise self-consumption to a maximum in electrotechnical systems with self-power generation. All relevant data for the application are measured, displayed and used for the control. The measured values are stored if desired when a microSD card is activated and shown on the 2-line (2x16 digits) display. Displayed measured values are voltage L1 L2 L3 current L1 L2 L3 power L1 L2 L3 and the total currents and powers. Calculated values are PNutz, work, energy, regenerated energy. Other values displayed are frequency, status of the 4 relays, date and time, SD card status, SD card free memory, Ethernet IP and the MAC address.

Function

The currents to be measured are measured either directly via the supplied current transformers or via additional current transformers. The voltage is always measured directly (according to the connection diagram). The main function of the unit is to detect the current surplus energy, calculated by U.I, and thus to control a continuously controllable consumer with exactly this amount of energy. This is done via the analogue outputs 0/1-10V or 0/4-20mA. In addition, 4 relay make contacts with freely selectable power and switch-on times per day are available.

SCOPE OF DELIVERY & TECHNICAL DATA

Scope of delivery

1x SMARTFOX Pro 2 energy consumption controller
1x Micro SD Card
1X Current transformer 3-phase up to 80A | 100A

Technical data

SMARTFOX Pro

Rated current 4995A	80A 100A or via additional transformer
Nominal voltage	3X230V/400V
Voltage range	185-265V
Nominal frequency	50Hz
Self-consumption	4W
Overload continuous	Voltage max. 265V, current 260A
Surge overload	Voltage 1000V 65µs
Relay switching	5A/250VAC max. resistive Consumer
View	2-line display here the current values can be read by pressing the keys.

Analogue outputs 0-10 VDC | 1-10VDC
0-20mA | 4-20mA

Connections L1/L2/L3/N/PE 3xL 1xN 1xPE 1.5mm²
Relay 1-4 4x 2x1,5mm²
Analogue outputs pluggable Gnd/I+/V+/24VDC 1mm²
Converter Pluggable 1xRJ12 6pol.

Interfaces WLAN | 100Mbps/s Ethernet LAN

Communication S0 input | CAN | RS485

Temperature input PT1000

SCOPE OF DELIVERY & TECHNICAL DATA

REGULATIONS

EMC	DIN EN61326
Mechanical strength	DIN EN 61010 Part 1
Electrical safety	DIN EN 61010 Part 1 Housing with protective insulation, protection class II, for working voltages up to 600V (mains to neutral) pollution degree 2, measurement category CAT III
Accuracy, overload air	DIN EN 60688
Disconnection and creepage distance	DIN EN 61010 Part 1, 3, 3KV 50Hz 4s DIN EN 61010 Part 1
Protection class connection	DIN EN 60529 Housing IP21 DIN 43807

WARNING!

This unit may only be installed by a qualified electrician, otherwise there is a risk of fire or electric shock!

Dimensions [WxHxD]

147mm x 90mm x 58 Width 8TE

Assembly

Top-hat rail mounting. At ambient temperatures of $>45^{\circ}\text{C}$, however, a distance of 10mm is recommended. The mounting location should be as vibration-free as possible and must not exceed an ambient temperature of 55°C .

Electrical Connection

The regulations for the installation of electrical systems must be observed, according to DIN 43807, via screw connection max. 1.5mm^2 . When installing the current transformer, the correct current direction K and L must be observed (K corresponds to the power supply company side, L corresponds to the system side).

ATTENTION!

When connecting the voltage input variable, the assignment to the current connection is important, i.e. the respective terminal of the voltage connection must also be located in the outer conductor in which the current transformer is located.


Hedging

REGULATIONS

When connecting, ensure that a suitable back-up fuse is used (line protection). The unit itself is internally fused.


6

INSTALLATION OF THE SMARTFOX CURRENT TRANSFORMER



Attention! The SMARTFOX current transformers must always be connected as shown in the picture above. (Arrows point in the direction of the consumer).

SMARTFOX ADDITIONAL CURRENT TRANSFORMER




WARNING!

The SMARTFOX current transformer cable must not be cut (loss of warranty).

NOTE!


The SMARTFOX current transformer set can be extended up to 15m. A suitable current transformer extension must be used for this.

CONNECTION DIAGRAM POWER CONTROLLER & HEATING ROD 1-PHASE



OPTIONAL

CONNECTION DIAGRAM POWER CONTROLLER & HEATING ROD 3-PHASE



ATTENTION!

Current and voltage path must always be the same!




ATTENTION!

Star connection required. NO NEUTRAL CONDUCTOR AT STAR POINT ! Only balanced loads

po

ssible!

CONNECTION DIAGRAM CONSUMER VIA RELAY



NAVIGATING THROUGH THE MENU



Use the arrow keys left or right to scroll through the menu. To change a value/setting, press the Enter key (cursor starts flashing). Use the arrow keys up or down to change the set value. To navigate to the first line, press the left arrow key repeatedly until the cursor jumps to the first line (cursor must flash).

Key combinations

Restart (5 seconds)



Firmware update (10 seconds)



Component and output test (5 seconds)



INSTRUCTIONS FOR FIRMWARE UPDATE

1. Download firmware from www.smartfox.at/downloads.
Version EM2 00.00.01.37

2. Remove the SD card.



3. Unzip the downloaded file and copy the .bin file into the main directory of the SD card.



4. Insert the SD card into the unit.



5. Press and hold the left and right arrow keys simultaneously for 10 seconds.



6. When the buttons are released, the display flashes several times and the update is started.

7. After the update, check the firmware version on the display!

DISPLAY OF THE MEASURED VALUES

NOTE!

After connecting the power supply, the unit starts and automatically switches to the menu DISPLAY MEASUREMENTS.

Performance and PNutz

*L e a s t = 2 0 w p n u
t z = 0 w*

POWER = 20W The current power is displayed. 20 Watt current consumption, drawn from the mains. There is a return delivery to the mains when a minus value is displayed, e.g. -20W.

PNUTZ= 500W. Currently, 500W is used via the analogue output (stepless). This is a calculated value according to the setting of the nominal load and the level of the analogue output. As soon as ANALOG OVERV is displayed under PNUZ, analogue monitoring is active. This means that the connected consumer is no longer consuming power (e.g. thermostat of the heating element has switched off). After 5 minutes, the system checks again to see if the consumer is consuming power again.

Energy purchase

*B E C A U S E N E R G I E = 5
7 . 0 4 K W H*

Purchased energy = The total energy purchased from the grid.

Energy delivery

*l i e v e r n e r g i e s =
0 . 4 7 k w h*

Delivery energy = The total energy fed back into the grid.

DISPLAY OF THE MEASURED VALUES

Analogue output energy

*ANALOGANERGIE = 0
. 00 KWH*

Analogue output energy = the total energy used by SMARTFOX/analogue output.

Voltage

*SPANNE : A = 234 V B
= 235 V, C = 234 V*

Voltage A=234V B=235V, C=236V. The measured mains voltage per phase is displayed. (A=L1, B=L2, C=L3).

Power

*STROM : A = 0.35 A
B = 0.00 A C = 0.35*

A

Current A= 0.35A B= 0.00A C=0.35A. The measured current per phase is displayed (A=L1, B=L2, C=L3).

Power

*P (W/KW) : A = - 82
WB = 0.00 W C = 80
W*

P(W/kW): A=-82W B=0.00W C=80W. The measured power is displayed (A=L1=- 82W, B=L2=0.00W, C=L3=80W). 82 watts are fed back into the mains on conductor L1.

fe

d back into the mains. 80 watts are drawn from conductor L3. The sum of the 3 conductors gives the total power (Pges = -82W + 0W + 80W =-2W supply to the mains).

Frequency

*frequency : 50.1
h Z*

Frequency: 50.1Hz, The current mains frequency is displayed. (50.1Hz)

DISPLAY OF THE MEASURED VALUES

DISPLAY OF THE MEASURED VALUES

Temperature

TEMPerature
50c

If a suitable sensor is connected to the PT1000 interface, the measured temperature is displayed here.

Analogue out

analogout = 25%
AUTOMATIC

ANALOGOUT = 25%. The current level of the analogue output is displayed. There are 3 operating modes available:

- 1. Switched off:** The output is switched off and is not controlled.
- 2. Automatic:** The output is automatically controlled by the SMARTFOX depending on the surplus situation.
- 3. Manual:** The output can be set to a process value regardless of the surplus situation.

ATTENTION! Energy can be drawn from the mains.

Relay

relaisr1 = 0r2
= 0r3 = 1r4 = m

RELAY R1-R4: The current switching state of the relay is displayed. There are 3 operating modes available:

- 0:** The relay is switched off.
- 1:** The set switch-on condition is fulfilled, the relay has been switched on by the SMARTFOX.
- M:** The relay can be switched on regardless of the surplus situation.

ATTENTION! Energy can be drawn from the mains.

DISPLAY OF THE MEASURED VALUES

Car Charger

```
CC - VALUE = 000% CO  
NSUPPLEMENT
```

CC-VALUE the current control level of the charging station is displayed. The current charging mode is displayed.

- 1. Switched off** - the charging station does not release a charge
- 2. Excess charge** - automatic control by SMARTFOX
- 3. Forced charging** - manual charging, the desired CC value must be set.

ATTENTION! Energy can be drawn from the mains.

SD card setting

```
SDCARD EINF  
R E I 1890MB
```

If a micro SD card is inserted and the setting is activated, all measurement data are written to the SD card at intervals of 30s. The unit creates a separate CSV file for each day (24h). Before removing the SD card, set the setting to "OFF". Micro SD cards up to 8GB are supported. The SD card must be formatted to FAT32. The free memory of the card is displayed in the second line.

PV Power and Energy

```
PV - P = 0.00KWP  
V - E = 0.00KWH
```

PV-P= The current produced power of the selected inverter. PV-E= The total energy produced by an inverter. Display as soon as an inverter has been connected.

Battery

```
bATTERY  
soc = 90%
```

The current state of charge (SOC) of the read-out battery is displayed.

MAIN MENU

Version

```
version  
em200.001.37
```

The currently installed software version is displayed.

WLAN - Version

```
wlanversion  
190502
```

The currently installed WLAN VERSION is displayed.

MAC address

```
macadresse  
D880568EF8AA
```

The MAC address of the device is displayed. This is required to integrate the SMART- FOX into the web portal my.smartfox.at.

IP address

```
ipadresse192.  
168.001.001
```

The currently obtained IP address is displayed.

WIFI AP / WIFI WPS

```
wifiaponwif  
iwpsoff
```

The access point and the WPS function of the SMARTFOX device can be activated here.


WIFI Access Point

If you set AP to ON, the SMARTFOX activates its access point. A WLAN with the name Smartfox_AP is now available. You can now connect to the SMARTFOX WIFI with your smartphone, laptop or tablet. To do this, open your network settings on the laptop, for example, and select the WLAN Smart-

fox_AP off. The PC will automatically connect to the SMARTFOX network (no password required). Open your web browser and enter the IP address 192.168.250.181. You can now access the SMARTFOX via the web interface, make settings or switch outputs.

Connection WLAN via access point

If you are connected to the access point of the SMARTFOX, the unit can be paired with an Internet-capable WLAN in the "NETWORK" menu.




1. Select the menu item "NETWORK"
2. Select the desired WLAN to which the SMARTFOX should connect.

NOTE!

Check the signal strength of the WLAN, preferably with the distribution door closed.

3. Select "Dynamic" if the network configuration is to be carried out automatically. (DHCP)
Select "Static" if the IP address is to be assigned permanently.
4. Click on "Save & Connect".

MAIN MENU



5. Enter the WLAN password and click on "OK".

SMARTFOX deactivates the access point and connects to the registered WLAN or Internet.

6. Connect your laptop, smartphone... to the same network that was selected on the SMARTFOX. The SMARTFOX can now be reached locally via the obtained IP address or <http://dafi-smartfox>. If the WLAN is Internet-enabled, the SMARTFOX can now be connected to the web portal my.smartfox.at.

Connection WLAN via WPS

1. Press the WPS button on your router
2. On the SMARTFOX, set the WIFI WPS setting to "ON".

The SMARTFOX now connects to the router's transmitted WLAN.

NOTE!

WPS2 cannot be used because password entry is not possible on the SMARTFOX. In this case, use the connection via the access point.

MAIN MENU

a n a g e m e n t s

By clicking on the ENTER button you enter the measured values menu.

The descriptions of the submenus can be found in the section "Displaying the measured values".

Getting started with the settings

P A S S W O R T = 0 0 0 0

To enter the settings menu, enter the password 2345 and confirm with ENTER.

The descriptions of the submenus can be found in the "Settings" section.

NOTE!

All settings can also be made internally via local network access or the my.smartfox.at web portal.

SETTINGS - GENERAL

Current transformer

```
STROMWANDLER  
EXTERN040:1
```

When connecting with the supplied standard 80A or 100A converters (RJ12 plug), 1:1 is set here. With additional transformers, you can choose between 2 and 999, depending on the transformer ratio (e.g. 200:5 transformer results in a ratio of 40:1 $200:5=40$). Thus, a maximum transformer ratio of 4995A can be achieved with 5A transformers.

NOTE!

For connection of additional transformer, see page 8.

Log Interval Setting

```
LOGINTERVAL  
030SEC
```

All measured values are written to the SD card at the set log interval. A minimum log interval of 30s can be set.

ATTENTION!

No data is saved if the SD card is not activated.

Setting Date Time

```
DATUM and Page 2  
018/06/0610:10
```

Setting the date and time.

SETTINGS - GENERAL

Synchronisation time server (NTP)

*Preserver
automatic*

Activated: The time is automatically synchronised by the NTP server.

Deactivated: The time is not synchronised. The system time of the Smartfox must be set manually

Time zone

*CONTRIBUTION
GMT: + 0 1*

The current time zone can be selected here.

Fernwartung

*FERNWARTUNG
EIN*

To be able to carry out parameterisation via the web interface, this must be set to ON.

SETTINGS - NETWORK

Network

NETZWERK:LAN

Select the desired LAN / WLAN interface with which the SMARTFOX is to connect to the Internet.

DHCP

d h c p : a n

DHCP ON: The network settings (IP, netmask, gateway) are queried

qu

eried automatically by the router.

DHCP OFF: The network settings (IP, Netmask, Gateway) can be selected manually.

IP address

IPADRESSE
192.168.001.10
3

The current IP address is displayed. Setting only possible if DHCP: "OFF" has been selected.

Netmask

NETMASK
255.255.255.00
0

The current netmask is displayed. Setting only possible if DHCP: "OFF" has been selected.

Gateway

GATEWAY192.16
8.001.001

The current gateway is displayed. Setting only possible if DHCP: "OFF" has been selected.

SETTINGS - NETWORK

Server IP

```
s E R V E R I P 0 9 3 .  
1 8 9 . 0 2 5 . 1 8 2
```

The IP address of the my.smartfox.at server is 93.189.25.182. Port TCP80 & TCP5000 are required to connect to the server.

Upload interval

```
U P L O A D I N T E R V A L L
```

Specifies the upload interval at which archive data (energy, power...) are uploaded from the Smartfox to the portal.

A minimum interval of 15min can be set. (This setting has no influence on the connection of the Liveview).

SETTINGS - ANALOGUE OUTPUT

U/IOUT

UOUT: 0 - 10V
IOUT: 0 - 20M

A

Voltage output - UOUT

Setting of the voltage output. It can be selected between 0-10V & 1-10V. The voltage output is pre-parameterised to 0-10V by default.

Current output - IOUT

Setting of the current output. You can choose between 4-20mA and 0-20mA. The current output is already pre-parameterised to 4-20mA.

Controller behaviour

REGLERP = 300WVE
R = 3

Set the nominal power of the connected consumer (heating rod) here. The setting of the nominal power should be very precise, as this value is used as the basis for the PNUTZ calculation.

The setting BEHAVIOUR specifies how nimble or sluggish the analogue output reacts. The value can be set between 1 (very fast) and 10 (very slow). By default, the value is set to 3 (nimble).

Target value

CIELWERT = -0020W
ANALOGUBERW. = AIN

Setting TARGET VALUE between -30000W & +30000W, set the desired value here to which the system is to be constantly regulated. To avoid drawing energy from the mains, a negative value should be set here. The standard setting -20W is very suitable here.

ATTENTION! If there is a battery storage in the system, the target value must be set to at least -200W to avoid charging the heating element from the battery.

Power controller

SETTINGS - ANALOGUE OUTPUT

LEADINGSTATES
I - PHASI
G

Select whether a 1-phase or 3-phase power controller is controlled. The setting increases the accuracy of the analogue curve, but has no influence on the control behaviour of the power controller.

Forced engagement

TANGESSERVIC
ES

Here you can set the timed forced release for the analogue output in the event of insufficient surplus energy in order to ensure hot water preparation without an external source.

s t a r t
0 0 : 0 0

Enter the switch-on time for the daily forced release.

l a n g e
1 0 0 m i n

The daily duty cycle of the forced release.

LEISTUNG
1 0 0 %

Specifies how high the power controller should be controlled during forced release. In most cases, a level of 100% is recommended.

SETTINGS - ANALOGUE OUTPUT

MODUS

AUTOMATIC

MODE indicates whether the time already run in automatic mode should be deducted or not (A=Automatic time is deducted, M=Manual time is not deducted).

*restlandcontri
bution*

000min

The remaining time of the analogue output during forced release is displayed here.

SETTINGS - RELAY 1 - 4

Possible control behaviour - Relay 1 - 4

r I W A E R M E P U M P E Z
W = E I N P N = E I N

Standard control behaviour (parameterisable to all relays)
Consumer | Heat pump | Load shedding

Special control behaviour

Analogue relay (R1) | heating rod 2 (R2 & R3) | 1ph/3ph (R4)

Settings Standard control behaviour

Regulation to target value - ZW

On: The target value set at the analogue output is taken into account.

Off: The switch-on threshold is calculated from target value 0.

Regulation with Pnutz - PN


Decides whether the relay is prioritised over the analogue output or not.

On: The relay is prioritised over the analogue output.

Off: The analogue output is prioritised over the relay.

Consumer


Under the control behaviour consumer, the relay is activated as soon as the set power P for the selected on-delay TD was surplus and switches off again after TH has expired. The test procedure of TD starts again.



SETTINGS - RELAY 1 - 4


Heat pump

Under the control behaviour heat pump, the relay is activated as soon as the set power P for the selected switch-on delay TD was surplus. If there is still enough surplus after the hold time TH has elapsed, the system does not switch off but starts the next cycle.



Load shedding

Under the control behaviour load shedding, the relay is activated as soon as the set power P for the selected switch-on delay TD has been drawn from the mains. If more energy than the set threshold value is still drawn after the holding time TH has expired, the relay remains active. Only when the mains draw is below the set threshold is the relay switched off after the switch-off delay has expired.



SETTINGS - RELAY 1 - 4

Relay 1 - 4

*R I N = 0 0 0 T D = 0 0 M P
= 0 0 0 0 W T H = 0 0 0 M*

Switch-on cycles per day - N

"Switch-on cycles per day" is the value of how often a relay is to be activated per day. This can be set between 0 and 999. 0 means that the relay is deactivated and is therefore not taken into account. If the relay is to be activated as often as possible, 999 can be selected.

Rated power in watts - P

"Nominal power in watts" is the power value of the consumer connected to the relay, adjustable from 1 to 9999 watts. The selected value is used as the switch-on threshold.

Switch-on delay in min - TD

"Switch-on delay in min" is the delay time how long the set power must be surplus under P to activate the relay. Adjustable between 0 and 99 minutes.

Holding period in minutes - TH

"Holding time in minutes" is the minimum time the relay remains activated after the switch-on condition is fulfilled, adjustable between 1 and 999 minutes. If, for example, a TH of 5min is set and the surplus collapses after 3 minutes (switch-on condition no longer fulfilled), the relay remains active for another two minutes.

Attention! To activate the relay, at least "1" must be entered here. become.

Switch-off delay (only for control behaviour heat pump and load shedding) Relay switches off after the set time (0 to 999s) has elapsed and the set switch-off threshold has been exceeded.

Switch-off threshold (only for control behaviour heat pump and load shedding)

The switch-off threshold can be set between -99999W and +99999W and indicates from which value the relay should deactivate again. By default, the relay switches off as soon as the value rises above 0. To keep the relay active, a value of +500W can be set, for example (+500W = supply; -500W = delivery).

SETTINGS - RELAY 1 - 4

Forced release relay

```
R1FNST = 00:00DU  
R = 000MMODE = A
```

R1 designates relay 1.

Start time - ST

Enter the switch-on time for the daily forced release.

Duration in minutes - DUR

The daily duty cycle of the forced release.

MODE

"MODE" indicates whether the time previously run in automatic mode is to be deducted or not (A=Automatic; time is deducted, M=Manual; time is not deducted).

Display of the running times


```
R1FNrest = 000  
mrllaft = 000m
```

The remaining running time and the already run running time of relay 1 for the forced release are displayed here.

SETTINGS - RELAY SPECIAL FUNCTIONS

R1 - Analogue relay

If the Analogue relay control behaviour is selected, the relay switches as soon as the analogue monitoring is activated. This means whenever the heating element at the analogue output is no longer consuming power (e.g. thermostat switched off). In this way, several heating rods can be operated continuously one after the other by switching the contactor at the output of the power controller (e.g. boiler-buffer switchover). Only the setting P is required for the relay; the nominal power of the second heating element must be stored here.



Analogue relay settings

```
r1 analogrelais  
ZW = EINPN = EIN
```

Select the control behaviour of the analogue relay.

NOTE! Heating rod 1 is parameterised at the analogue output.

```
R1N = 000TD = 00MP  
= 0600WTH = 000M
```


Set the nominal power of the second heating rod under P.

Complete instructions Analogue relay function at www.smartfox.at/downloads

SETTINGS - RELAY SPECIAL FUNCTIONS

R2 or R3 - 2nd heating element - Temperature changeover via PT1000

The "2nd heating element" function is only active if a temperature sensor is connected to the PT1000 input. The relay switches on when the set changeover temperature of the sensor is reached and switches off again when the temperature falls below this by 2°C. This offers the possibility of switching between two heating rods at the analogue output by means of a temperature sensor. This offers the possibility of switching between 2 heating elements at the analogue output by means of the temperature sensor (e.g. boiler-buffer switchover, heating element above - heating element below). Only the setting P is required for the relay; the nominal output of the second heating rod must be stored here and the changeover temperature must be defined.



Settings heating rod2

```
r2heizstab2ZW  
=EINPN=EIN
```

SETTINGS - RELAY SPECIAL FUNCTIONS

Select control behaviour of heating rod2.

SETTINGS - RELAY SPECIAL FUNCTIONS

R 2 N = 0 0 0 T D = 0 0 M P
= 0 6 0 0 W T H = 0 0 0 M

Set the nominal power of the second heating rod under P.

u m s c h a l t e m
p 6 0 c

Set the desired changeover temperature.

ATTENTION!

The connection of a PT1000 temperature sensor is required for the function.

Complete instructions "2nd heating rod function" at www.smartfox.at/downloads

SETTINGS - INPUTS & CONSUMPTION CONTROLLERS

Inputs

INPUTS0

Settings menu of the integrated S0 interface.

Input S0

S0Input:Wechselrichter

Select the desired application of the S0 input here.

Complete instructions S0 input at www.smartfox.at/downloads

Pulses per unit

*PulsesperUnit
0100prokWh*

Enter the pulse rate of the connected S0 meter here.

Temperature sensor ON / OFF

*TEMPERATURSensor
ON*

The function of a PT1000 temperature sensor can be activated here.

Minimum temperature

Mindest-Temperatur:40C

The minimum temperature that is always to be maintained via the analogue output can be set here.

Maximum temperature

Maximal-Temperature: 60C

The maximum temperature to be reached by excess energy can be set here.

ATTENTION!

Minimum temperature and maximum temperature function only possible with connected PT1000 temperature sensor.

Consumption controller

verbrauchsregler

A consumption controller can be set here instead of an analogue output.
e.g. Ohmpilot RTU or TCP depending on the interface (RS485 = RTU, LAN or WLAN = TCP).

Complete [instructions Ohmpilot](http://www.smartfox.at/downloads) at www.smartfox.at/downloads

SETTINGS - INVERTER, HEAT PUMP & BATTERY

Inverter setting

```
AC-CONV. = FRONIUS  
S192.168.001.180
```

Select the inverter to be read here.

The complete instructions for the various inverters (Fronius, SolarEdge, Kostal, etc.) can be found at www.smartfox.at/downloads.

Enter the statically assigned IP address of the inverter here. The static IP address can be omitted if the "IP Scan" setting is activated. Using the IP scan, it can take up to 15 minutes until the IP address is displayed.

NOTE!

After licence activation up to 5 inverters possible!

Complete [instructions for licence activation](http://www.smartfox.at/downloads) at www.smartfox.at/downloads

IP address inverter

```
IPSCAN =  
any
```

If the IP scan is activated, the entry of the static IP address can be omitted. This setting is only possible for the 1st inverter.

Heat pump

```
waermepumpe: id  
m192.168.001.10  
2
```

After licence activation, enter the IP address of the WP to be controlled.

Battery

```
BATTERY: FRONIUS  
S192.168.001.024
```

After activating the licence, enter the IP address of the battery storage unit to be read.

Complete [Licence Activation](http://www.smartfox.at/downloads) and Battery Storage Instructions at www.smartfox.at/downloads

SETTINGS SMARTFOX CAR CHARGER

*Charger: cebab
f.002sreg.006*

Select the manufacturer/factory of the charging station.

NOTE!

Car Charger licence (art. no. 0791732486568) required.

Complete [Car Charger instructions](http://www.smartfox.at/downloads) at www.smartfox.at/downloads

MAINTENANCE MENU

Maintenance password

To enter the maintenance menu, enter 9876.

Delete all energy meters

*allenergies - c
aehlerloesche*

n

Max U

*MAXU: A = 231VB
= 231V, C = 231V*

Maximum voltage. Maximum values measured on the unit since commissioning.

Max I

*MAXI: A = 4AB
= 4AC = 4A*

Maximum current. Maximum values measured on the unit since commissioning.

Max P

*MAXP: A = 970WB =
951W, C = 967W*

Maximum power: Maximum values measured on the unit since commissioning.

Operating hours

*BECAUSESSTANDS
200H*

Operating hours measured on the unit since commissioning.

MAINTENANCE MENU

LOCAL NETWORK ACCESS

All settings and switching operations can be carried out via local network access.

1. Read the current IP address in the MAIN MENU, e.g. 192.168.1.52.
2. Computer, laptop, smartphone... connect to the same network
3. Enter the current IP address of the SMARTFOX in the web browser.
4. The local web page of the SMARTFOX opens.

NOTE!

As an alternative to the IP address, the command `http://dafi-smartfox` can also be entered to open the local website


If no network is available, the local website can also be reached via the WIFI access point.

1. In the MAIN MENU, set WIFI AP to "ON"
2. SMARTFOX sends out the WLAN "Smartfox_AP".
3. With a computer, laptop, smartphone...connect to the WLAN.
4. Open the web browser and enter the IP address 192.168.250.181.
5. The local web page of the SMARTFOX opens.


Analogausgang	Bezug	R1	R2	R3	R4
0.000 kW	0.164 kW	0	0	0	0
-0.001 kW	0.000 kW	24.7 °C	-1 %		
PV Power	Car Charger Power	Temperatursensor	Batterie SOC		

CONNECTION WITH MY.SMARTFOX.AT

1. Register at my.smartfox.at.
2. Click on "Add device".



3. Assign a name for the unit.
4. Enter the MAC address of the SMARTFOX. (See display main menu).
5. Click on "Save".



6. If the plug symbol is displayed in green, the unit is connected to the portal. You can now make all settings via the web portal and use all monitoring functions.



MISSING SEARCH

1. The measurement does not work properly.

Check the mounting of the current transformers (in the direction of the arrow).

2. The control of the heating rod does not work.

Check whether the heating element is connected according to the installation instructions. Check the safety thermostat on the heating element. This must be actuated if necessary. Check the settings of the heating element for completeness. Check the "ANALOGOUT" setting, this must be set to "AUTOMATIC". If the heating element still does not work, there may be a defect in one of the installed components.

3. My SMARTFOX is in operation but does not show any characters on the display.

Carry out a firmware update.

4. I cannot find my SMARTFOX on the network.

Please check the network connection. Please check the network settings on the SMARTFOX (router IP/subnetmask).

5. The SD card on my SMARTFOX keeps switching off.

The memory card is full or no longer has a free root directory available. Insert a FAT32 formatted SD card (min. 4GB max. 8GB).

6. The update cannot be started.

Disconnect the power supply to your SMARTFOX device and press and hold the two right-hand buttons (<- , ->), then reactivate the power supply and release the two buttons again after approx. 10 seconds. The screen starts flashing and SMARTFOX starts the update.

More information at: <http://smartfox.at/support.html>

DAfi GmbH
Niedernfritzerstraße 120
A-5531 Eben im Pongau

+43 6458 20 160
support@smartfox.at